

EPA Lake Champlain River Geographic Response Strategy Swanton LC-VT-						
Tactic #	Purpose	Response Equipment	Deployment Resources	Deployment Notes		
DV-01	Redirect spilled oil from one location or direction of travel to a specific site for recovery.	800 ft protected water boom 4 marine anchor system 2 shoreline anchor system Testing Date	2 shore responders 1 response boats 1 boat operators N Tested	Deploy boom as depicted to divert incoming oil to the collection site. Anchor every 200- 300'. Adjust configuration as necessary to reduce entrainment. Set up shoreside recovery. Deploy shoreside anchor first.		
SR-01	Remove spilled oil that has been diverted to a designated recovery site accessible from shore.		2 shore responders Tested	Set up shoreside recovery tactic at general location depicted on map.		

		hic Response Strategy al contacts		
All VT Fire Departments		Call 911		
EPA Region 1 Tribal Pro	gram	617-918-1123		
Missisquoi National Wild	life Refuge	802-868-4781		
National Response Cent	er	800-424-8802		
VT Comm. on Native Am	nerican Affairs	802-779-7015		
VT DEC (24-Hour)		800-641-5005		
VT Drinking Water & Gro	oundwater	802-741-5311		
VT Emergency Mgmnt &	Homeland Security	800-347-0488		
VT Fish & Wildlife Dept (802-878-1564		
VT Hazmat Response Te		800-641-5005		
VT Div of Historical Pres		802-272-2509	-	
VI DIV OF HISTORICAL Pres	ervation	802-212-2009		
			A	
			_	
			SLAD.	
			5	
	Resourc	ces Protected		
Fish	No available data		10000000000	
Birds	No available data		1.6	
Threat/End. Species	Rare, Threatened, and			
Cultural/Historical	Historical/Archaeologica	- Aller		
Resources		A BOUND		
Human Use	Boat Ramp, Lock & Da			
Land Management	No available data			
Riverine	No available data			
Lake and river conditions rain or snowfall.		ional Hazards d stage vary depending on the time of year and heavy	Survey site prior to de	
If ice is present GRS tac	tics and strategies must be	e reevaluated.		
Vessel operators should	have local knowledge and	experience operating in riverine environments.		



Swanton LC-VT-04

Aerial view of Missisquoi River at Swanton Dam. Goose Point Park and site of DV-01 at upper right corner.



No available data	Goose Point Park boat ramp at site of DV-01. View looks north/northeast.	
No available data		
Navigational Hazards	Special Considerations	
ions such as flow rate and flood stage vary depending on the time of year and heavy	Survey site prior to deployment and modify deployment tactics and techniques as appropriate based on observed river/lake conditions.	
tactics and strategies must be reevaluated.		
uld have local knowledge and experience operating in riverine environments.		