

Tactics Legend

- DF** Deflection Booming
- DV** Diversion Booming
- EX** Exclusion Booming
- FO** Free Oil Recovery
- PR** Passive Recovery
- SR** Shoreside Recovery
- S** Staging Area
-  Boat Ramp
-  Kayak Ramp
-  Railroad
-  Protected-Water Boom
-  Protected-Water Boom (Ebb Tide)
-  Snare/ Sorbent Boom



Equipment - All Tactics

Boom(ft)	1500
Marine anchors	8
Shore anchors	6
Sorbent Boom(ft)	0
FO Recovery Sys	0
Shore Responders	2
Boat Responders	2
Boats	2

Tactics Deployment, Responder Safety, and GRS Data Information




Always consider on-scene conditions before deploying GRS tactics. Responder safety should always be the first priority.

Location

Latitude: 44° 41' 20"
Longitude: 73° 20' 57"
State: Vermont

Version

9/20/2022

Tactic #	Purpose	Response Equipment	Deployment Resources	Deployment Notes
C-01 	Isolate a spill and control spreading to reduce impact to the surrounding environment and concentrate oil to facilitate recovery.	800 ft protected water boom 4 marine anchor system 2 shoreline anchor system	2 shore responders 1 response boats 1 boat operators	Place protected-water boom in the water around or in the vicinity of the source. Sorbent boom and/or pads can be placed inside boom to recover oil. Tend as necessary based on wind and water flow. Deploy shoreside anchor first.
		Testing Date	N Tested	
EX-02a 	Prohibit oil slicks from entering a sensitive area.	600 ft protected water boom 3 marine anchor system 2 shoreline anchor system	2 shore responders 1 response boats 1 boat operators	Deploy boom as depicted to exclude oil from sensitive areas. Anchor every 200-300'. Adjust configuration as necessary to reduce entrainment. Deploy shoreside anchor first.
		Testing Date	N Tested	
EX-02b 	Prohibit oil slicks from entering a sensitive area.	100 ft protected water boom 1 marine anchor system 2 shoreline anchor system	2 shore responders 1 response boats 1 boat operators	Deploy boom as depicted to exclude oil from sensitive areas. Anchor every 200-300'. Adjust configuration as necessary to reduce entrainment. Deploy shoreside anchor first. Readjust boom angle as needed to reduce entrainment
		Testing Date	N Tested	

